

RESTORATION TIPS

Removing & Installing the starter on the C-10 -

This little jewell can be "something else" to get on and off but with this tip it sure makes it easier.

1. Remove-car-body from-frame-
2. Remove all wiring and cover bare battery cable to prevent arking.
3. Remove top bolt and get a stud with same threads as this bolt. Install stud in place of top bolt so stud will hold the starter. Stud must extend approx. $1\frac{1}{4}$ " beyond the mounting flange of the starter.
4. Remove lower bolt and starter will stay in place until you are back on top of engine to remove.
5. When installing starter, "hang" starter in place on the stud and install lower bolt first. As you tighten lower bolt, move starter occasionally to "seat" starter in fly-wheel housing. Tighten lower bolt until snug, then remove stud and install upper bolt & tighten. Retighten lower bolt and replace wiring. (You probably removed the splash pan before removing starter - replace)

O.P. Higbee