Glad you asked that

A LIST OF PART NUMBERS THAT MAY BE HELPFUL IN RESTORING AND MAINTAINING OUR AIRFLAN CARS. It should be noted that I have a C-10 and therefore, in most cases the numbers are peculiar to Chryslers and in some cases do not apply to Chrysler Airflows of other models.

Harry	
Clutch Press Assem - 3org & Beck Model 871 Universal Joint - Borg ''arner '36 & '37 1 Brake hoses - Bendix (front) 8	544 3613 3747 3748 5 49
MOTOR PARTS	404
Timing Chain - Borg Warner Timing Chain Sprocket (for crankshaft) Cloyes Valve Springs - Sealed Power V. Camshaft Bearings - Sealed Power (set) Rear Main Bearing - Federal Mogul 9 FrontMain Bearing - Federal Mogul 9 Center Main Bearing - Federal Mogul 9 Rod Bearings - Federal Mogul 9 Rod Bearings - Federal Mogul 9 Rod Bearings - Federal Mogul 9 Valves, intake - Thompson V. Toledo V. Chrysler 6 Valves, exhaust - Thompson S Toledo APC -Nu Krome 8 Chrysler 6 Exhaust Valve Seat Insert (same O.D. as Dodge) Thompson I Oil Pan Gasket - Victor 3 Head Gasket - Victor 8 McCord 6	S-305 079-M 973-SB 331-SB 331-SB 333-SB 645-SB -836 -945 23652 -835 -944 39