

SHOP TIP

A common failure in old Chryslers is the sagging door handles. Simply unscrew the outside handle brackets and remove the handle, put the square end in a vise, heat slightly, and bend the shank to compensate for the wear factor. --Bill Honeycutt